


## Connections

Thread union in T form, GVS-T


**FEZER**  
Simply move more.



GVS-T



GVS-T ... I



GVS-T ... I ... A- ... I

### Article number

Type		Weight (kg)
GVS-T-1/8I	6.21.5.0828	0,020
GVS-T-1/8I-1/8A-1/8I	6.21.5.0830	0,030
GVS-T-1/4I	6.21.5.0416	0,040
GVS-T-1/4I-1/4A-1/4I	6.21.5.0657	0,040
GVS-T-3/8I	6.21.5.0829	0,050
GVS-T-3/8A-3/8A-3/8I	6.21.5.0831	0,050
GVS-T-1/2I	6.21.5.0636	0,100
GVS-T-1/2A-1/2A-1/2I	6.21.5.0832	0,070

### Dimensions

Type	L1	G1	G2	HG1	SW
GVS-T-1/8I	19	G1/8	G1/8	8,5	12
GVS-T-1/8I-1/8A-1/8I	19	G1/8	G1/8	8,5	12
GVS-T-1/4I	23	G1/4	G1/4	11	13
GVS-T-1/4I-1/4A-1/4I	23	G1/4	G1/4	11	13
GVS-T-3/8I	25	G3/8	G3/8	11,5	16
GVS-T-3/8A-3/8A-3/8I	25	G3/8	G3/8	11,5	16
GVS-T-1/2I	31,5	G1/2	G1/2	14	20
GVS-T-1/2A-1/2A-1/2I	31,5	G1/2	G1/2	14	20


## Connections

Thread union in TW form, GVS-TW

**FEZER**  
Simply move more.



GVS-TW



GVS-TW- ...

### Article number

Type		Weight (kg)
GVS-TW-1/8I-1/8I-1/8A	6.21.5.0860	0,022
GVS-TW-1/4I-1/4I-1/4A	6.21.5.0861	0,037
GVS-TW-3/8I-3/8I-3/8A	6.21.5.0862	0,049
GVS-TW-1/2I-1/2I-1/2A	6.21.5.0863	0,089

### Dimensions

Type	L1	L2	G1	G2	HG1	SW
GVS-TW-1/8A-1/8I	28,5	19	G1/8	G1/8	8,5	12
GVS-TW-1/4A-1/4I	35	23	G1/4	G1/4	11	13
GVS-TW-3/8A-3/8I	37	25	G3/8	G3/8	11,5	16
GVS-TW-1/2A-1/2I	45,5	31,5	G1/2	G1/2	14	20