


Connections

Thread union straight, GVS-G


FEZER
Simply move more.



GVS-G



GVS-G- ... A



GVS-G- ... I

Article number

Type		Weight (kg)
GVS-G-1/8A	6.21.5.0833	0,010
GVS-G-1/8I	6.21.5.0835	0,010
GVS-G-1/4A	6.21.5.0641	0,015
GVS-G-1/4I	6.21.5.0426	0,020
GVS-G-3/8A	6.21.5.0834	0,020
GVS-G-3/8I	6.21.5.0836	0,020
GVS-G-1/2A	6.21.5.0661	0,040
GVS-G-1/2I	6.21.5.0640	0,030

Dimensions

Type	L1	L2	G1	HG1	SW
GVS-G-1/8A	19,5	7,5	G1/8	7,5	12
GVS-G-1/8I	15	7,5	G1/8	7,5	13
GVS-G-1/4A	27	11	G1/4	11	14
GVS-G-1/4I	22	11	G1/4	11	17
GVS-G-3/8A	28	11,5	G3/8	11	17
GVS-G-3/8I	23	11,5	G3/8	11	20
GVS-G-1/2A	33,5	14	G1/2	11	22
GVS-G-1/2I	28	14	G1/2	11	24


Connections

Thread union angular, GVS-W


FEZER
Simply move more.



GVS-W



GVS-W- ... A



GVS-W- ... I

Article number

Type		Weight (kg)
GVS-W-1/8I	6.21.5.0825	0,015
GVS-W-1/8A-1/8I	6.21.5.0827	0,015
GVS-W-1/4I	6.21.5.0427	0,030
GVS-W-1/4A-1/4I	6.21.5.0584	0,030
GVS-W-3/8I	6.21.5.0826	0,040
GVS-W-3/8A-3/8I	6.21.5.0580	0,030
GVS-W-1/2I	6.21.5.0639	0,070
GVS-W-1/2A-1/2I	6.21.5.0525	0,060

Dimensions

Type	L1	H1	G1	G2	HG1	SW
GVS-W-1/8I	19	11,5	G1/8	G1/8	8,5	11
GVS-W-1/8A-1/8I	19	11,5	G1/8	G1/8	8,5	11
GVS-W-1/4I	23	15	G1/4	G1/4	11	14
GVS-W-1/4A-1/4I	23	15	G1/4	G1/4	11	13
GVS-W-3/8I	25	15	G3/8	G3/8	11,5	16
GVS-W-3/8A-3/8I	25	15	G3/8	G3/8	11,5	15
GVS-W-1/2I	31,5	17,5	G1/2	G1/2	14	20
GVS-W-1/2A-1/2I	31,5	17,5	G1/2	G1/2	14	20