


Connections

Plug-in connector in T form SVB-T

FEZER
Simply move more.



SVB-T



SVB-T

Article number

Type		Hose-Ø (mm)	Weight (kg)
SVB-T-4	6.21.5.0759	4	0,0070
SVB-T-6	6.21.5.0760	6	0,0100
SVB-T-8	6.21.5.0761	8	0,0150
SVB-T-10	6.21.5.0534	10	0,0250
SVB-T-12	6.21.5.0762	12	0,0350
SVB-T-16	6.21.5.0763	16	0,0400

Dimensions

Type	D1	D2	D3	H1	H2	X1
SVB-T-4	4	10	3,2	21,9	16,9	13
SVB-T-6	6	13	3,5	26,6	20,1	16
SVB-T-8	8	15	3,5	29,7	22,2	18
SVB-T-10	10	17,5	4,2	33,95	25,2	24
SVB-T-12	12	21	4,2	38,7	28,2	28
SVB-T-16	16	25	4,2	45,6	33,1	24


Connections

Plug-in connector in Y form SVB-Y

FEZER
Simply move more.



SVB-Y



SVB-Y

Article number

Type		Hose-Ø (mm)	Weight (kg)
SVB-Y-4	6.21.5.0764	4	0,0070
SVB-Y-6	6.21.5.0765	6	0,0098
SVB-Y-8	6.21.5.0683	8	0,0150
SVB-Y-10	6.21.5.0766	10	0,0250
SVB-Y-12	6.21.5.0767	12	0,0350
SVB-Y-16	6.21.5.0768	16	0,0450

Dimensions

Type	D1	D2	D3	L1	L2	H1	X1
SVB-Y-4	4	10	3,2	21	11	32,8	18,6
SVB-Y-6	6	12,5	3,2	24,5	12	37,7	21,9
SVB-Y-8	8	14,5	3,2	28,5	14	42,4	25,2
SVB-Y-10	10	17,5	4,2	35,5	18	48,4	28,9
SVB-Y-12	12	21	4,2	41	20	54,8	32,6
SVB-Y-16	16	25	4,5	49	24	62,2	40,1